

## Device Type

Ampex DCT-700	SIF-3
Ampex TBC-7	AIF-3
Ampex Zeus TBC	SIF-5
DPS-265 Frame Sync	SIF-2
Panasonic AJ-HD150	SIF-8
Panasonic AJ-HD1700	SIF-8
Panasonic AJ-SD965	AIF-2
Panasonic D3 / D5	SIF-1
Panasonic MII	AIF-2
Sony BVH-2000	AIF-1
Sony BVH-3000	AIF-1
Sony BVH-3100	AIF-1
Sony BVU-800 / 820	AIF-1A
Sony BVU-950	AIF-1A
Sony BVW-10 / 40	AIF-1
Sony BVW-65 / 70 / 75	AIF-1
Sony BVW-D75	AIF-1
Sony DVR-10 / 18 / 28	SIF-1
Sony DVW-500 / A500	AIF-1
Sony HDW-2000	SIF-7B
Sony HDW-500	SIF-7B
Sony MAV-555	SIF-7B
Sony MSW-M2000	AIF-1
Sony PVW-2600 / 2800	AIF-1A
Sony SRW-5000	SIF-7B
Sony UVW-1800	AIF-1A
Tektronix 110 Frame Sync	AIF-4
Tektronix VS-210 Frame Sync	SIF-4